



PESO	0,710 KG
CANTIDAD DE PRODUCTO EN EL PAQUETE	1

MARCA	OEM
ZF	1312 332 028
RENAULT	5001843123
IVECO	8198837
DAF	1227597
MAN	81.90713-0154
MERCEDES	000 264 3976

MARCA	TIPO
ZF	16 S 190 PLANET/17.06-1.00
ZF	16 S 220 PLANET/10.14-0.72
ZF	16 S 220 PLANET/13.80-0.84
ZF	16 S 220 PLANET/16.47-1.00
ZF	16 S 220A PLANET/14.14-0.86
ZF	16 S 220A PLANET/16.87-1.02
ZF	16 S 151 PLANET/NEW MODEL
ZF	16 S 181 PLANET
ZF	16 S 221 PLANET/NEW MODEL
ZF	16 S 251 PLANET
ZF	16 S 1621 TD IT PLANET
ZF	16 S 1620 TD PLANET
ZF	16 S 162 TD IT PLANET
ZF	16 S 1625 TD PLANET
ZF	16 S 1823 TO PLANET

MARCA	TIPO
ZF	16 S 1820 TO PLANET
ZF	16 S 182-1821 TO IT PLANET
ZF	16 S 1822-1825 TO PLANET
ZF	16 S 1820 TO/STEERING PUMP
ZF	16 S 182-1821 TO IT/STEERING PUMP
ZF	16 S 1822-1825 TO/STEERING PUMP
ZF	16 S 1823 TO/STEERING PUMP
ZF	16 S 1620 TD/STEERING PUMP
ZF	16 S 1625 TD/STEERING PUMP
ZF	16 S 162 TD IT/STEERING PUMP
ZF	16 S 1621 TD IT/STEERING PUMP
ZF	16 S 251/STEERING PUMP
ZF	16 S 221/STEERING PUMP
ZF	16 S 181/STEERING PUMP
ZF	16 S 151/STEERING PUMP
ZF	16 S 1923 TD PLANET
ZF	16 S 1920 TD PLANET
ZF	16 S 1921 TD IT PLANET
ZF	16 S 1922 TD PLANET
ZF	16 S 1920 TD/STEERING PUMP
ZF	16 S 1921 TD IT/STEERING PUMP
ZF	16 S 1922 TD/STEERING PUMP
ZF	16 S 1923 TD/STEERING PUMP
ZF	16 S 2221 TO IT PLANET
ZF	16 S 2222 TO PLANET
ZF	16 S 2220 TO/TO IT PLANET
ZF	16 S 222 TO IT PLANET
ZF	16 S 2223 TO PLANET
ZF	16 S 2225 TO PLANET
ZF	16 S 2220 TO/TO IT/STEERING PUMP
ZF	16 S 222 TO IT/STEERING PUMP
ZF	16 S 2222 TO/STEERING PUMP
ZF	16 S 2223 TO/STEERING PUMP
ZF	16 S 2225 TO/STEERING PUMP
ZF	16 S 2221 TO IT/STEERING PUMP
ZF	16 S 2221 TD IT PLANET
ZF	16 S 2220 TD PLANET
ZF	16 S 222 TD IT PLANET
ZF	16 S 2222 TD PLANET
ZF	16 S 2223 TD PLANET
ZF	16 S 2225 TD PLANET
ZF	16 S 2220 TD/STEERING PUMP
ZF	16 S 222 TD IT/STEERING PUMP
ZF	16 S 2222 TD/STEERING PUMP
ZF	16 S 2223 TD/STEERING PUMP

MARCA	TIPO
ZF	16 S 2225 TD/STEERING PUMP
ZF	16 S 2221 TD IT/STEERING PUMP
ZF	16 S 2321 TD IT PLANET
ZF	16 S 2320 TD PLANET
ZF	16 S 232 TD IT PLANET
ZF	16 S 2322 TD PLANET
ZF	16 S 2323 TD PLANET
ZF	16 S 2325 TD PLANET
ZF	16 S 2320 TD/STEERING PUMP
ZF	16 S 232 TD IT/STEERING PUMP
ZF	16 S 2322 TD/STEERING PUMP
ZF	16 S 2323 TD/STEERING PUMP
ZF	16 S 2325 TD/STEERING PUMP
ZF	16 S 2321 TD IT/STEERING PUMP
ZF	16 S 2521 TO IT PLANET
ZF	16 S 2520 TO PLANET
ZF	16 S 252 TO IT PLANET
ZF	16 S 2522 TO PLANET
ZF	16 S 2523 TO PLANET
ZF	16 S 2525 TO PLANET
ZF	16 S 2520 TO/STEERING PUMP
ZF	16 S 252 TO IT/STEERING PUMP
ZF	16 S 2522 TO/STEERING PUMP
ZF	16 S 2523 TO/STEERING PUMP
ZF	16 S 2525 TO/STEERING PUMP
ZF	16 S 2521 TO IT/STEERING PUMP
ZF	16 S 272/2721 TO IT PLANET
ZF	16 S 2723/2725 TO PLANET
ZF	16 S 2723/2725 TO/STEERING PUMP
ZF	16 S 272/2721 TO IT/STEERING PUMP
ZF	1355-12 S 2530 TD PLANET
ZF	1355-12 S 253 TD IT PLANET
ZF	1355-12 S 2531 TD IT PLANET
ZF	1355-12 S 2533 TD PLANET
ZF	1355-12 S 2330 TD PLANET
ZF	1355-12 S 2333 TD PLANET
ZF	1355-12 S 233 TD IT PLANET
ZF	1355-12 S 2331 TD IT PLANET
ZF	1355-16 S 1635 TD PLANET
ZF	1355-16 S 1620 TD PLANET
ZF	1355-16 S 162 TD IT PLANET
ZF	1355-16 S 1621 TD IT PLANET
ZF	1355-16 S 1625 TD PLANET
ZF	1355-16 S 1630 TD PLANET
ZF	1355-16 S 163 TD IT PLANET

MARCA	TIPO
ZF	1355-16 S 1631 TD IT PLANET
ZF	1355-16 S 1835 TO PLANET
ZF	1355-16 S 1820 TO PLANET
ZF	1355-16 S 182 TO IT PLANET
ZF	1355-16 S 1821 TO IT PLANET
ZF	1355-16 S 1830 TO PLANET
ZF	1355-16 S 183 TO IT PLANET
ZF	1355-16 S 1831 TO IT PLANET
ZF	1355-16 S 1833 TO PLANET
ZF	1355-16 S 1935 TD PLANET
ZF	1355-16 S 1920 TD PLANET
ZF	1355-16 S 1921 TD IT PLANET
ZF	1355-16 S 1923 TD PLANET
ZF	1355-16 S 1925 TD PLANET
ZF	1355-16 S 1930 TD PLANET
ZF	1355-16 S 193 TD IT PLANET
ZF	1355-16 S 1931 TD IT PLANET
ZF	1355-16 S 1933 TD PLANET
ZF	1355-16 S 2033 TD PLANET
ZF	1355-16 S 2030 TDL PLANET
ZF	1355-16 S 203 TDL IT PLANET
ZF	1355-16 S 2033 TDL PLANET
ZF	1355-16 S 2030 TD PLANET
ZF	1355-16 S 2031 TD IT PLANET
ZF	1355-16 S 2225 TD PLANET
ZF	1355-16 S 2220 TO PLANET
ZF	1355-16 S 2221 TO IT PLANET
ZF	1355-16 S 2223 TO PLANET
ZF	1355-16 S 2225 TO PLANET
ZF	1355-16 S 2220 TD PLANET
ZF	1355-16 S 2221 TD IT PLANET
ZF	1355-16 S 2223 TD PLANET
ZF	1355-16 S 2235 TD PLANET
ZF	1355-16 S 2230 TO PLANET
ZF	1355-16 S 223 TO IT PLANET
ZF	1355-16 S 2231 TO IT PLANET
ZF	1355-16 S 2233 TO PLANET
ZF	1355-16 S 2235 TO PLANET
ZF	1355-16 S 2230 TD PLANET
ZF	1355-16 S 223 TD IT PLANET
ZF	1355-16 S 2231 TD IT PLANET
ZF	1355-16 S 2233 TD PLANET
ZF	1355-16 S 2333 TD PLANET
ZF	1355-16 S 2320 TD PLANET
ZF	1355-16 S 232 TD IT PLANET

MARCA	TIPO
ZF	1355-16 S 2321 TD IT PLANET
ZF	1355-16 S 2323 TD PLANET
ZF	1355-16 S 2325 TD PLANET
ZF	1355-16 S 2330 TD PLANET
ZF	1355-16 S 233 TD IT PLANET
ZF	1355-16 S 2331 TD IT PLANET
ZF	1355-16 S 2535 TO PLANET
ZF	1355-16 S 2520 TO PLANET
ZF	1355-16 S 2521 TO IT PLANET
ZF	1355-16 S 2523 TO PLANET
ZF	1355-16 S 2525 TO PLANET
ZF	1355-16 S 2530 TO PLANET
ZF	1355-16 S 2531 TO IT PLANET
ZF	1355-16 S 253 TO IT PLANET
ZF	1355-16 S 2533 TO PLANET
ZF	1355-16 S 2731 TO IT PLANET
ZF	1355-16 S 2733 TO PLANET
ZF	1355-16 S 2735 TO PLANET
ZF	1355-16 S 273 TO IT PLANET
ZF	12 AS TRONIC PLANET/12 AS TD-TO
ZF	12 AS TRONIC PLANET/12 AS TD-TO / IT
ZF	16 AS TRONIC PLANET/16 AS TD-TO
ZF	16 AS TRONIC PLANET/16 AS TD-TO / IT
ZF	12 TRAXON - PLANET/12 TX TD-TO
ZF	12 TRAXON - PLANET/12 TX TD-TO IT
ZF	12 TRAXON - PLANET/12 TX BD-BO IT