



AĞIRLIK 0,110 KG

PAKETTEKİ ÜRÜN ADETİ 1

MARKA	OEM
ZF	0750 111 341 - 0734 319 551

MARKA	TİPİ
ZF	16 S 1650 PLANET/PLANET/DG
ZF	16 S 1650 PLANET/PLANET/SG
ZF	16 S 130 PLANET/10.14-0.72
ZF	16 S 130 PLANET/11.46-0.85
ZF	16 S 130 PLANET/13.68-1.00
ZF	16 S 130 PLANET/14.29-0.82
ZF	16 S 160 PLANET/11.46-0.85
ZF	16 S 160 PLANET/13.68-1.00
ZF	16 S 160 PLANET/14.29-0.82
ZF	16 S 160 PLANET/17.06-1.00
ZF	16 S 190 PLANET/11.46-0.85
ZF	16 S 190 PLANET/13.68-1.00
ZF	16 S 190 PLANET/14.29-0.82
ZF	16 S 190 PLANET/17.06-1.00
ZF	16 S 150 PLANET/13.80-0.84
ZF	16 S 150 PLANET/16.47-1.00
ZF	16 S 220 PLANET/10.14-0.72
ZF	16 S 220 PLANET/13.80-0.84
ZF	16 S 220 PLANET/16.47-1.00
ZF	16 S 151 PLANET/OLD MODEL

MARKA	Tipi
ZF	16 S 151 PLANET/NEW MODEL
ZF	16 S 181 PLANET
ZF	16 S 221 PLANET/OLD MODEL
ZF	16 S 221 PLANET/NEW MODEL
ZF	16 S 251 PLANET
ZF	16 S 1625 TD PLANET
ZF	16 S 1620 TD PLANET
ZF	16 S 1823 TO PLANET
ZF	16 S 1820 TO PLANET
ZF	16 S 1822-1825 TO PLANET
ZF	16 S 150/P.T.O.(POWER TAKE OFF)
ZF	16 S 220/P.T.O.(POWER TAKE OFF)
ZF	16 S 220A/P.T.O.(POWER TAKE OFF)
ZF	16 S 151/SEAL KIT
ZF	16 S 181/SEAL KIT
ZF	16 S 221/SEAL KIT
ZF	16 S 251/SEAL KIT
ZF	16 S 1620 TD/SEAL KIT
ZF	16 S 1625 TD/SEAL KIT
ZF	16 S 162 TD IT/SEAL KIT
ZF	16 S 1621 TD IT/SEAL KIT
ZF	16 S 1820 TO/SEAL KIT
ZF	16 S 182-1821 TO IT/SEAL KIT
ZF	16 S 1822-1825 TO/SEAL KIT
ZF	16 S 1823 TO/SEAL KIT
ZF	16 S 1820 TO/STEERING PUMP
ZF	16 S 182-1821 TO IT/STEERING PUMP
ZF	16 S 1822-1825 TO/STEERING PUMP
ZF	16 S 1823 TO/STEERING PUMP
ZF	16 S 1620 TD/STEERING PUMP
ZF	16 S 1625 TD/STEERING PUMP
ZF	16 S 162 TD IT/STEERING PUMP
ZF	16 S 1621 TD IT/STEERING PUMP
ZF	16 S 251/STEERING PUMP
ZF	16 S 221/STEERING PUMP
ZF	16 S 181/STEERING PUMP
ZF	16 S 151/STEERING PUMP
ZF	16 S 1923 TD PLANET
ZF	16 S 1920 TD PLANET
ZF	16 S 1922 TD PLANET
ZF	16 S 1920 TD/SEAL KIT
ZF	16 S 1921 TD IT/SEAL KIT
ZF	16 S 1922 TD/SEAL KIT
ZF	16 S 1923 TD/SEAL KIT
ZF	16 S 1920 TD/STEERING PUMP

MARKA	Tipi
ZF	16 S 1921 TD IT/STEERING PUMP
ZF	16 S 1922 TD/STEERING PUMP
ZF	16 S 1923 TD/STEERING PUMP
ZF	16 S 2223 TO PLANET
ZF	16 S 2220 TO/TO IT PLANET
ZF	16 S 2222 TO PLANET
ZF	16 S 2220 TO/TO IT/SEAL KIT
ZF	16 S 222 TO IT/SEAL KIT
ZF	16 S 2222 TO/SEAL KIT
ZF	16 S 2223 TO/SEAL KIT
ZF	16 S 2225 TO/SEAL KIT
ZF	16 S 2221 TO IT/SEAL KIT
ZF	16 S 2220 TO/TO IT/STEERING PUMP
ZF	16 S 222 TO IT/STEERING PUMP
ZF	16 S 2222 TO/STEERING PUMP
ZF	16 S 2223 TO/STEERING PUMP
ZF	16 S 2225 TO/STEERING PUMP
ZF	16 S 2221 TO IT/STEERING PUMP
ZF	16 S 2225 TD PLANET
ZF	16 S 2220 TD PLANET
ZF	16 S 2222 TD PLANET
ZF	16 S 2223 TD PLANET
ZF	16 S 2220 TD/SEAL KIT
ZF	16 S 222 TD IT/SEAL KIT
ZF	16 S 2222 TD/SEAL KIT
ZF	16 S 2223 TD/SEAL KIT
ZF	16 S 2225 TD/SEAL KIT
ZF	16 S 2221 TD IT/SEAL KIT
ZF	16 S 2220 TD/STEERING PUMP
ZF	16 S 222 TD IT/STEERING PUMP
ZF	16 S 2222 TD/STEERING PUMP
ZF	16 S 2223 TD/STEERING PUMP
ZF	16 S 2225 TD/STEERING PUMP
ZF	16 S 2221 TD IT/STEERING PUMP
ZF	16 S 2325 TD PLANET
ZF	16 S 2320 TD PLANET
ZF	16 S 2322 TD PLANET
ZF	16 S 2323 TD PLANET
ZF	16 S 2320 TD/SEAL KIT
ZF	16 S 232 TD IT/SEAL KIT
ZF	16 S 2322 TD/SEAL KIT
ZF	16 S 2323 TD/SEAL KIT
ZF	16 S 2325 TD/SEAL KIT
ZF	16 S 2321 TD IT/SEAL KIT
ZF	16 S 2320 TD/STEERING PUMP

MARKA	Tipi
ZF	16 S 232 TD IT/STEERING PUMP
ZF	16 S 2322 TD/STEERING PUMP
ZF	16 S 2323 TD/STEERING PUMP
ZF	16 S 2325 TD/STEERING PUMP
ZF	16 S 2321 TD IT/STEERING PUMP
ZF	16 S 2525 TO PLANET
ZF	16 S 2520 TO PLANET
ZF	16 S 2522 TO PLANET
ZF	16 S 2523 TO PLANET
ZF	16 S 2520 TO/SEAL KIT
ZF	16 S 252 TO IT/SEAL KIT
ZF	16 S 2522 TO/SEAL KIT
ZF	16 S 2523 TO/SEAL KIT
ZF	16 S 2525 TO/SEAL KIT
ZF	16 S 2521 TO IT/SEAL KIT
ZF	16 S 2520 TO/STEERING PUMP
ZF	16 S 252 TO IT/STEERING PUMP
ZF	16 S 2522 TO/STEERING PUMP
ZF	16 S 2523 TO/STEERING PUMP
ZF	16 S 2525 TO/STEERING PUMP
ZF	16 S 2521 TO IT/STEERING PUMP
ZF	16 S 2723/2725 TO PLANET
ZF	16 S 2723/2725 TO/SEAL KIT
ZF	16 S 272/2721 TO IT/SEAL KIT
ZF	16 S 2723/2725 TO/STEERING PUMP
ZF	16 S 272/2721 TO IT/STEERING PUMP
ZF	16 S 130/P.T.O.(POWER TAKE OFF)
ZF	16 S 160/P.T.O.(POWER TAKE OFF)
ZF	16 S 190/P.T.O.(POWER TAKE OFF)